




1.



2.



3.



Install accessories

A		3
B		1
C		2
D		2
E		2
F	M4x10	2

TV accessories

a		M8x25	4
b		M6x25	4
c		M5x20	4
d		M4x20	4
e			4
f			4
g		D8	4
h		D6	4